

*Instructions for Applying the*  
***ID UNIT #2-SI***  
*WITH*  
***TIRE-TRACK "SUPER GLUE"***

**HOW TO APPLY THE "SI" - ID UNIT TO A TIRE:**

1. Select an area approximately ½" above the heel of the Bead. Buff area until smooth and "velvet-like" texture.
2. Spray Tire Cleaner Fluid (Patch Rubber or Tech International products) on select area, **ALLOW TO PENETRATE FOR AT LEAST 1 MINUTE**. Scrape clean with scraper and allow to completely dry. Repeat this process until the area is clean.
3. Spray a small amount of cleaner fluid on a clean cloth and wipe the "black" side of the ID Unit, to remove any contaminants.
4. **Shake the bottle** of Super Glue and apply to the black side of the ID Unit (about a "dime-size" circle). Spread Super Glue over cleaned area with a brush or plastic knife.
5. Place, press & hold the ID Unit onto the tire until it sets (about 1 minute). After it sets, rub the ID Unit to remove any trapped air.
6. Allow to dry for at least 2 hrs at room temperature (above 60 degrees), longer if cooler. Maximum adhesion does not occur before 24hrs.

***If You Have Any Questions, Please Call:***

*TIRE-TRACK LLC*  
2<sup>nd</sup> Floor · 440 Main St. · Ridgefield, CT 06877  
(203) 438-8687      **(800) 227-5592**